

# Catalyst Carrier


Newsletter

Issue 02 / 2010


## Designing Porous Particles

### 1 Specialty Silica Fundamentals

SIPERNAT® Specialty Silica are produced by acidification of an aqueous alkali silicate solution. The primary particles, which are initially generated, subsequently form aggregates and agglomerates. This leads to sponge-like structures and particle sizes typically in the micrometer range. Figure 1 illustrates schematically the structure of Specialty Silica and Figure 2 features a micrograph of a typical SIPERNAT® Specialty Silica surface, showing the sponge-like agglomerate structure with numerous pores of different sizes.



**Figure 1**  
Structure of Specialty Silica




**Figure 2**  
SEM Image of Surface and Pore Structure of Specialty Silica

### 2 Designing Porosity

For silica-supported catalyst applications, the specific surface area of the silica is highly important. We have addressed the need for high surface area silica types with our products SIPERNAT® 50 and SIPERNAT® 310. They show a specific surface area of 500 m<sup>2</sup>/g and 700 m<sup>2</sup>/g respectively; however, these grades are best characterized as classical Specialty Silica and thus show a broad pore size distribution with part of the surface area to be found in the micropore range. Under further processing (such as extrusion and calcination) of these silica grades a significant fraction of the micropores, and hence surface area, will be lost. To address this at times limiting phenomenon, Evonik has specifically designed a class of mesoporous Specialty Silica types.

Three examples of these mesoporous silica grades are EXP 4210-1, 4215-1 and 4230-1. They combine a well-defined pore size distribution, which is usually found in silica gels, with the good processability of Specialty Silica during granulation or extrusion. Figure 3 shows the pore size distribution of these three experimental silica grades.


**Figure 3**Pore size distribution (N<sub>2</sub> desorption) of mesoporous EXP grades

— EXP 4210-1    — EXP 4215-1    — EXP 4230-1

Another unique type of Specialty Silica is SIPERNAT® 350. This macroporous grade is ideally suited whenever large molecules such as biocatalysts need to be fixed on a silica support. Figure 4 shows the pore size distribution of this grade (measured by Hg intrusion).

**Figure 4**

Pore size distribution (Hg intrusion) of SIPERNAT® 350



### 3 Product Overview

A selection of recommended grades and their typical properties is given below. These data should be seen only as an example; further variation, according to the customers need, is possible. Contact us. Challenge us.

### 4 Conclusion – SIPERNAT® Specialty Silica

Because Evonik can design the pore structure of SIPERNAT® Specialty Silica by carefully controlling the reaction conditions, a wide portfolio of products is available to meet our customers' needs. Look to the SIPERNAT® trade name for a broad range of Specialty Silica grades with different particle morphologies, surface areas and well adjusted pore size distributions.

**Table 1**

Properties of selected silica types. The values given are typical data and not part of the specification.

Silica Grade	Specific surface area (N <sub>2</sub> ) TriStar Multipoint following ISO 9277 [m <sup>2</sup> /g]	Particle Size, d50 Laser diffraction following ISO 13320-1 [μm]	Description
EXP 4210-1	560	< 20	EXP 4210-1 is a mesoporous silica with high surface area and an average pore size in the 10 nm range.
EXP 4215-1	350	< 30	EXP 4215-1 is a mesoporous silica with medium surface area and an average pore size in the 15 nm range.
EXP 4230-1	290	< 10	EXP 4230-1 is a mesoporous silica with medium surface area and an average pore size in the 20 nm range.
SIPERNAT® 50	500	50	SIPERNAT® 50 is a high surface area silica with a wide pore size distribution.
SIPERNAT® 310	700	8.5	SIPERNAT® 310 is a high surface area silica with a wide pore size distribution.
SIPERNAT® 350	55	4.5	SIPERNAT® 350 is a macroporous silica with low surface area and an average pore size in the 150 nm range.

## North America

### Evonik Degussa Corporation

Inorganic Materials  
379 Interpace Parkway  
P.O. Box 377  
Parsippany, NJ 07054-0677  
USA

PHONE +1 888 745-4227

FAX +1 732 981-5310

catalyst-carrier-nafta@evonik.com

## Asia / Pacific

### Evonik Degussa (SEA) Pte. Ltd.

Inorganic Materials  
3 International Business Park  
#07-18 Nordic European Centre  
Singapore 609927

PHONE +65 6 890-6031

FAX +65 6 890-6872

catalyst-carrier-asia@evonik.com

This information and all technical and other advice are based on Evonik's present knowledge and experience. However, Evonik assumes no liability for such information or advice, including the extent to which such information or advice may relate to third party intellectual property rights. Evonik reserves the right to make any changes to information or advice at any time, without prior or subsequent notice. EVONIK DISCLAIMS ALL REPRESENTATIONS AND WARRANTIES, WHETHER EXPRESS OR IMPLIED, AND SHALL HAVE NO LIABILITY FOR, MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR A PARTICULAR PURPOSE (EVEN IF EVONIK IS AWARE OF SUCH PURPOSE), OR OTHERWISE. EVONIK SHALL NOT BE RESPONSIBLE FOR CONSEQUENTIAL, INDIRECT OR INCIDENTAL DAMAGES (INCLUDING LOSS OF PROFITS) OF ANY KIND. It is the customer's sole responsibility to arrange for inspection and testing of all products by qualified experts. Reference to trade names used by other companies is neither a recommendation nor an endorsement of the corresponding product, and does not imply that similar products could not be used.



## Europe / Middle-East / Africa / Latin America

### Evonik Degussa GmbH

Inorganic Materials  
Rodenbacher Chausse 4  
63457 Hanau-Wolfgang  
Germany

PHONE +49 6181 59-4858

FAX +49 6181 59-4096

catalyst-carrier-eu@evonik.com

[www.evonik.com](http://www.evonik.com)

**Evonik. Power to create.**